



TOP GUN HEADACHE RACK INSTALATION INSTRUCTIONS

Ford Super Duty 99-09 : Part # 230 500 9900 (F250 & F350)

Dodge 03-09 1500,2500,3500 : Part # 210 500 0300

Chevy 03-07 classic body 1500,2500,3500 : Part # 220 500 0300

Chevy/GMC 07-09 new body 1500,2500,3500 : Part # 250 500 0700

Toyota Tundra , D-Cab, Crew Max 07-09 : Part # 160 500 0700

**** No Hardware Provided, Lights come with pigtail wire leads only****

1. Place Top Gun Headache rack on top of truck bed, closest to the cab of truck.
2. Make sure that center angle piece is snug up against bulk head.
3. Side rails should fit snug onto bed caps.

To wire lights, you must provide your own wire, connectors, electrical tape, electrical volt/amp meter.

All lights come with pigtail wire leads. The Headache rack is channeled to where the wires can go from top of Headache rack, down thru the 2in. Square tube on the drivers side, as most trucks wire harness run along drivers side of truck from front to back. You will need to find the proper wires to tie into.

Lights to be wired to truck owners discretion. I.e.: red lights can be for brake, turn or running lights. White lights can be wired to be extra reverse lights or extra cargo lights.

Securing Headache rack to truck can be done, either by installing bolts thru the holes in the side of the bed cap, or the top of the bed cap, or both. This is up to the Installer/ truck owner.

The slotted holes on the top of the bed cap are there for installing a tool box. If NOT installing a tool box, then you can install by using the holes in the side of the bed cap.

The side cap holes will allow up to a ¼ in. diameter bolt or self tapping screw. (bolts, nuts, washers)

The top cap holes will allow up to ½ in. diameter bolt. We do not recommend self tapping screws be placed in top cap holes. (bolts, nuts, washers)