



## TOYOTA TUNDRA 07-08 GRILLE GUARD

PART NUMBER 160 300 0700

TOOLS NEEDED : 14mm SOCKET OR WRENCH  
17mm SOCKET OR WRENCH  
19mm SOCKET OR WRENCH



1. Remove tow hooks. (will replace in next step)
2. Install grille guard frame brackets ( solid side facing out ) using tow hooks and factory bolts.
3. Mount grille guard to frame brackets. Insert carriage bolts from back side, thread nuts hand tight for now.
4. \* May be easier to get to factory bumper bracket by removing lower fender shroud.\*
5. Using top outside factory bumper bracket bolt, install grille guard upper support bracket, thru the outside air vent on the factory bumper. ( double slotted, some 07 models have a double bolts pattern on factory bumper bracket) Install other end (single slot) to inside of grille guard upright. Insert carriage bolt from outer side of upright. Hand tighten all bolts.
6. Align wings of grille guard to equal gap on each side between truck and wings.
7. Tighten all bolts to 70 lbs. of torque.

HARDWARE PROVIDED: 6 - CARRAIGE BOLTS  
6 - PLANGE NUTS  
2 - FRAME BRACKETS  
2 - UPPER SUPPORT BRACKETS

